

Setup Guide



**Electrocleansing with the
EB22 Electrobooster**

Table of Contents

Getting Started.....	1
Connecting the Cables.....	7
Running a Session.....	9
General Notes.....	12
Length and Frequency of Session.....	12
Placing the Pads.....	12
Monitoring	13
Making a Selection.....	13
Warnings and Safety Considerations.....	14

Electrocleansing.com
Electrobooster.com
2011-2014

Return Policy and Warranty

Return Policy: The EB22 is an experimental device and, therefore, we cannot offer refunds. All sales are final.

Warranty: Electrobooster.com warrants the EB22 against defects in material or workmanship for a period of one year from date of purchase. We will repair or replace unit at our discretion. Contact pads and gels are consumables and are not covered by this warranty. Warranty does not cover accident, misuse, or abuse. If the EB22 is not operating correctly, please contact us and we will provide troubleshooting. If necessary, all returns for repair must be pre-authorized and shipped prepaid.

Getting Started

You will need:

- EB22 Electrobooster Kit
- A computer or a laptop that is capable of sound.



1. To get started, visit the website:
www.Electrocleansing.com



2. Turn off any other programs running on your computer so they do not interrupt your session.


Note: Turning off music players and noisy websites is obvious, but even instant messaging programs running in the task bar can pop up and produce unexpected sound interference.

3. If you are planning to use the Electrobooster offline, download the program to your desktop. Click Download Program on the website and follow the directions for installation. Double click the “Electrocleansing.swf” icon on the desk top. Then click the “Maximize” button (center button at the top right of the Electrocleansing window) to expand to a full screen.




4. **OR** if you wish to run the program over the internet using a browser, follow the link **Run Electrocleansing**. Then click the F11 button to toggle to a full screen.


- Click on a disorder or specific frequency. To the right of the list is the pulse option. Pulsing the frequencies has been reported to be more effective.



- Enter desired minutes (20 minutes recommended).



- Press the play button to verify your sound system is working. You should hear a frequency being played.



Note: Adjust the volume. A lower volume will produce milder results, louder is stronger. Keep volume at moderate levels until familiar with the Electrobooster.

8. Once sound and volume has been verified, open the EB22 Electrobooster kit. For the protection of the machine, the case is waterproof and the latches can be a bit stiff.



9. The pads are stored in the lid, behind the foam. This is also a convenient place to store this manual.




10. The EB22 Electrobooster is designed to remain in the case during use.

You should have:

- One 12 volt power adapter cord (A)
- One white connector cable (B)
- One black sound cable (C)
- Optional 12 volt car adapter (D)

It may seem like a lot of cables, but don't worry. The jacks are different sizes and you can only plug the correct cable into the corresponding jack.




Connecting the Cables

1. **Plug the power cord (A)** into a power source. Make sure the volume is turned off before plugging the other end of the power cable into the power jack on the EB22 (marked **10-18VDC**)



2. **Plug the white connector cable (B)** into the jack labeled Pads. Make sure the plug goes in all the way and is firmly seated. Remove a pair of pads from the sealed envelope. (When not in use, store them in the sealed envelope to prevent them from drying out.) You will find that the connector cable splits into two at one end. Push each pin into an electrode connector.



3. **Plug the sound cable (C)** into the jack labeled Sound. Plug the other end of the sound plug into the headset jack on the computer (where headphones would be plugged in).




4. The machine is ready to use.




Running a Session

1. Electricity flows from one pad to the other through the body, generally in the shape of a football. Place a pad on each side of the area you are targeting. The intensity will be strongest where the pad is placed, but it will also effect the area between the pads.




Note: After the pads have been used many times, you may need to rub several drops of water into the pads to revive the stickiness. Also, if the pads are too old or well used, they may not be reliable electrical conductors. Replace with new ones.

2. Open the Electrocleansing program, either from your desktop or through a browser (See chapter *Getting Started* at the beginning of this guide). Select a disorder or specific frequency and a session time (20 minutes recommended).



3. Press the play button to start the session.



4. Turn the Intensity or volume knob just enough to click on. You should see the red power LED light up.



5. Turn the Speaker knob to full volume so you can hear what's going on. You can adjust it later.



6. Gently turn the Intensity or volume knob until you can hear and feel the electricity (typically between 1 and 3). Do this slowly and with caution until you find a comfortable level. The green Umph light will flash, indicating the strength and intensity.
7. After the session is completed, turn the Intensity dial to the off position before removing the pads from your body.
8. Remove the pads from the pins and place them back on the vinyl sheet. Return them to the envelope and seal it for safe storage.
9. Return the plugs and cables to the storage slot in the kit and the pads envelope to the area in the lid. Close the case and secure the latches. Store the EB22 in a convenient location for the next use.



General Notes

Length and Frequency of Session

Many people enjoy electrocleansing for 20 minutes or more, three times a week, though it's not recommended to exceed 60 minutes per day.

If you experience flu-like symptoms, reduce the frequency or duration of your sessions. The body needs time to flush out the toxins that are being stirred up. Drinking water or lemon water may also help.

Placing the Pads

The bottom of the feet is the least sensitive. Some areas of the body, such as legs or arms, cause muscles to flex back and forth with the pulsing. This is normal.

Some frequencies are felt much stronger than others. Frequency 727 is much more intense or hotter than 2 Hz.

As you turn up the large intensity or volume knob, you will feel a tingling sensation. Find an intensity that is comfortable for you. After a few minutes the sensation will start to drop away slightly. This is called “accommodation.” When this happens you can turn the volume up until it feels comfortable again.

Keep the intensity or volume control within easy reach so you can make adjustments. If you are running a variety of frequencies, you may need to adjust the knob each time a frequency changes.

Monitoring

Two colored lights monitor progress. The red power light shows that the unit is powered on. The green Umph meter pulses with the frequency. The stronger the green light pulses, the stronger the frequency being delivered.

If you want more Umph, you can adjust either the intensity or volume knob on the Electrobooster or turn up the volume on your computer.

Making a Selection


Select a disorder from the list on the computer screen by clicking once. The disorder will be highlighted. Disorders are made up of a bank of frequencies. If you don't know what disorder to use, choose the **Universal Healing Frequency**. This is the most popular setting. If you enjoy a particular frequency when it appears on the screen, it can be selected and run by itself. Individual frequencies are listed at the end of the disorders list.

Electrocleansing is enjoyable and relaxing. Have fun.

Warnings and Safety Considerations

USE COMMON SENSE

- Be careful on areas of the body that lack sensation. Don't turn the large knob too high just because you can't feel it.
- Do not remove the pads until the EB22 Intensity knob is turned down or off to avoid an uncomfortable sensation.



- Don't put the pads on the temples, or on sensitive areas of the body.
- Pregnant women should be cautious and not place pads over the uterus.
- This unit is not recommended for people with heart pacemakers.

